


## TS8120 VACUUM PICK & PLACE SYSTEM

### COMPLETE SYSTEM INCLUDES:

- Vacuum Console Control
- Pick Up Pen
- Two Vacuum Tips (15 & 23 Gauge)
- Five Rubber Cups
- Two 533 Connectors 3' Air hose

### INSTALLATION INSTRUCTIONS:



1. Attach mounting pads to the bottom surface of the console.
2. Connect one end of the air hose to the vacuum console air inlet port and connect the other end to the accessories air outlet port of the dispenser.
3. Connect the pickup pen to the vacuum inlet port of the console.
4. Attach appropriate tip and vacuum cup to the pickup pen assembly
5. Turn vacuum control knob counter clockwise to set vacuum pressure
6. To pickup part: Hold the pickup pen with the index finger covering the exhaust port.
7. To release part: Remove finger from exhaust port.

TSI-0103\_D